


Panasonic® GTWIN Installation Guide

■Introduction


- Exit all applications before installing GTWIN.
- Do not connect the GT unit and a PC before installing GTWIN.
A USB driver may not be automatically installed.
- For using GT series on a computer in which GTWIN Ver.2.F0 or older has been installed for the first time, a USB driver should be installed.
Prepare a GT unit and USB cable, and install the driver according to "Procedure of Installing USB Driver".

■Procedure


- (1) Execute [setup.exe].




- (2) When the right screen is displayed, click [Yes].



- (3) The right screen is displayed. Click [Next].



- (4) The right screen is displayed. Click [Yes] if you accept the license agreement. If you do not accept, click [No] to cancel the installation.




- (5) The right screen is displayed. Enter [User Name], [Company Name] and [Serial Number], and click [Next].


Note)

If the [Serial number] is wrong, the error message is displayed and you can not continue the installation.

- (6) The right screen is displayed. Select a language on GTWIN. (The selected language can be changed in GTWIN Configuration after installation.)




- (7) The right screen is displayed. For changing the destination folder, click [Browse] and select a folder. Click "Next" to continue the installation without change.



Note)

This screen is not displayed in the case of overwrite install.


- (8) The right screen is displayed. If you want to change the destination program folder, select a desired program folder. Click "Next" to continue the installation without change.




Note)

This screen is not displayed in the case of overwrite install.


- (9) The right screen is displayed. The installation process begins.



- (10) The right screen is displayed during the installation. Click [Yes] to confirm the content. Click [No] to continue to the next step without confirmation. (This content will be installed as a file "ReadmeEnu.txt". So you can confirm it later.)



- (11) The right screen is displayed. Click [Finish] and reboot the computer.



The installation is complete.

Note:

When installing on Windows 2000, a USB driver is not automatically recognized. By turning on the power supply of GT and connecting the GT to a PC with a USB cable, a dialog for specifying the location of the driver appears. Specify the following folder.

Folder to be specified:

¥Program Files¥Panasonic-ID SUNX Terminal¥GTWIN¥GTWIN_USB¥x86

For 64-bit edition of Windows, specify the following folder.

¥Program Files (x86)¥Panasonic-ID SUNX Terminal¥GTWIN¥GTWIN_USB¥x64

■Procedure of Installing USB Driver 【When installing on Windows(R) 7, 8】


- (1) Turn on the power supply of GT, and connect the GT and a PC with a USB cable.




- (2) The error message as below is displayed at the bottom right of the screen after the connection. Continue the installation procedure.




- (3) Access to Properties of your computer. Click [Start], select [Computer] and right-click [Properties].




- (4) Control Panel Home is displayed. Click "Device Manager" in the upper left part of the window.




- (5) Device Manager is displayed. Right-click "Panasonic GT" under [Other devices], and click [Update Driver].



- (6) Update Driver Software - Panasonic GT is displayed. Select "Browse my computer for driver software".



- (7) Confirm the place to search the driver. Press [Browse], and specify the following folder. Click [Next].




Folder to be specified:

¥Program Files¥Panasonic-ID SUNX Terminal¥GTWIN¥GTWIN_USB¥x86

For 64-bit edition of Windows, specify the following folder.

¥Program Files (x86)¥Panasonic-ID SUNX Terminal¥GTWIN¥GTWIN_USB¥x64

- (8) The installation process begins. A message is displayed on the screen indicating that the installation completed. Click [Close] to close the screen. If a Windows security message is displayed during installation, click [Install this driver software anyway] or [Install].





The installation of the USB driver has been completed.

【When installing on Windows Vista】


- (1) Turn on the power supply of GT, and connect the GT and a PC with a USB cable.




- (2) As the PC detects the connection of USB automatically and displays a dialog prompting to install a driver software, select "Locate and install driver software (recommended)". If the User Account Control dialog is displayed, click "Continue".



- (3) Found New Hardware - Panasonic GT is displayed. Select "I don't have the disc. Show me other options.".



- (4) Select "Browse my computer for driver software".



After that, perform the steps (7) and (8) of [When installing on Windows(R) 7, 8].

Panasonic Industrial Devices SUNX Co., Ltd.

http://panasonic.net/id/pidsx/global

Overseas Sales Division (Head Office)

2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan

Phone: +81-568-33-7861 FAX: +81-568-33-8591

[For our sales network, please visit our website.

PRINTED IN JAPAN

© Panasonic Industrial Devices SUNX Co., Ltd. 2016

8A3 Q42 7000 1